




AXIS TM5806-E Housing




Installation guide


AXIS TM5806-E Housing



1x




1x




3x



1.1





1.2




1.3



AXIS TM5806-E Housing




1.4






1.5


3x
1 Nm
(0.7 lb ft)






1.6



1.7




1.8




4x
1 Nm
(0.7 lb ft)




1.9




1.10






2.1




2.2








2.3




2.4



2.5



2.6





Installation guide
AXIS TM5806-E Housing
© 2024 Axis Communications AB

Ver. M1.2
Date: July 2024
Part no. 3110778